


ARGOSY, 32 Ft. EXTERIOR SHELL - ROADSIDE

Measurements to vertical pillars are from the front end seam to the center line of the pillar.


Measurements to the horizontal stringer is from the floor line up to the center line of the stringer.



ARGOSY 32 Ft. EXTERIOR SHELL - CURBSIDE

Measurements to vertical pillars are from the front end seam to the center line of the pillar.

Measurements to the horizontal stringer is from the floor line up to the center line of the stringer.




ARGOSY 32 Ft. EXTERIOR SHELL - ROOF

Measurements on roof stringers running lengthwise are taken from the center line of the trailer.

Measurements to roof bows running across the trailer are taken from the front roof end seam to the center of the bow.


FRONT →




ALL MEASUREMENTS TO STA. "0" or CENTER LINE

STA. "0" is the front roof end seam

ARGOSY ROOF, END VIEW




ARGOSY FRONT SHELL FRAME




- | | | | |
|---|---------------------------|----|----------------------------|
| 1 | Bow, Upper Right | 10 | Stringer, "C" Section |
| 2 | Bow, Upper Left | 11 | Pillar, "C" Section |
| 3 | Bow, Belt Line Left | 12 | Pillar, "C" Section |
| 4 | Bow, Belt Line Right | 13 | Stringer, "I" Section |
| 5 | Bow, Floor Right | 14 | Gusset |
| 6 | Bow, Floor Left | 15 | Gusset |
| 7 | Pillar, Right "C" Section | 16 | Pillar, "C" Section |
| 8 | Pillar, Left "C" Section | 17 | Gusset, Rock Guard Support |
| 9 | Stringer, "C" Section | 18 | Gusset |

ARGOSY FRONT SHELL PANELS




- 1 Panel, Belt Line
- 2 Cap, Front End Shell
- 3 Panel, Corner Upper Left
- 4 Panel, Corner Upper Right
- 5 Panel, Corner Lower Left
- 6 Panel, Corner Lower Right
- 7 Panel, Lower Center
- 8 Panel, Lower Side
- 9 Panel, Upper
- 10 Panel, Center Mullion

ARGOSY REAR SHELL FRAME



- | | | | |
|---|-----------------------|----|-----------------------|
| 1 | Bow, Upper | 10 | Stringer, "C" Section |
| 2 | Gusset | 11 | Stringer, "I" Section |
| 3 | Bow, Belt Line | 12 | Pillar, "C" Section |
| 4 | Gusset | 14 | Pillar, "C" Section |
| 5 | Bow, Floor | 15 | Pillar, "C" Section |
| 6 | Pillar, "C" Section | 16 | Pillar, "C" Section |
| 7 | Pillar, "C" Section | | |
| 9 | Stringer, "I" Section | | |

ARGOSY REAR SHELL PANELS



- 1 Panel, Lower
- 2 Cap Rear End Shell
- 3 Panel, Corner Upper Left
- 4 Panel, Corner Upper Right
- 5 Panel, Corner Lower Left
- 6 Panel, Corner Lower Right
- 7 Panel, Upper
- 8 Panel, Belt line